

OptiClean™ K is an aggressive low pH (acidic) powdered cleaner ideal for removing metal hydroxides such as iron and manganese, as well as calcium, magnesium and other similar scales from MF/UF/NF/RO membranes. Combining select water activated solubilizing agents, and strong chelants, OptiClean™ K has proven to be the ideal cleaner for membrane systems troubled by heavy inorganic scaling.

Features / Benefits

- Readily dissolvable powdered cleaner provides efficient shipping and handling
- Buffered pH to maintain optimum cleaning performance throughout cleaning cycle
- Best results when used in conjunction with either Lavasol™ 9 or Lavasol™ 7.

Uses

- For use on reverse osmosis (RO), nanofiltration (NF), ultrafiltration (UF) and micro-filtration (MF) membranes
- Formulated to dissolve inorganic precipitants from the membrane surface
- To aid in the removal of carbonates, phosphates, metal hydroxides and similar inorganic foulants

Specifications

Appearance	Clear Liquid
pH (1% solution)	1.50 - 2.50

Packaging

Pail: 25 lbs

Pail: 45 lbs

Pail: 55 lbs

Pail: 10 kg

Pail: 25 kg

Bulk Bag: 1000 kg

For special packaging options, please contact PWT or your local distributor.

OptiClean™ K
POWDER MEMBRANE CLEANER

OptiClean™ K

POWDER MEMBRANE CLEANER

General Mixing & Application Instructions for OptiClean™ K

1. Inspect all cleaning system components to include CIP tank, hoses, and cartridge filters. Flush or replace if necessary. Fill cleaning tank with RO permeate or DI water. Turn on agitator or tank recirculation pump.
2. Slowly add OptiClean™ K to cleaning tank (1 pound [0.45 kg] of OptiClean™ for every 12 gal [45L] of water) and mix thoroughly. The solution pH should match product specification. If necessary, adjust pH with a membrane-approved chemical such as caustic, citric, sulfuric, or hydrochloric acid. The solution should be heated up to 45°C to improve cleaning efficacy.
3. Circulate solution in the same direction as the feed flow. Typical circulation times are 30-90 minutes.* PWT recommends cleaning each stage of the system separately. Maximum flow rate per pressure vessel is 40 gpm (152 Lpm) for 8-inch elements and 10 gpm (38 Lpm) for 4-inch elements. Maximum pressure for cleaning is 60 psig (4.2 kg/cm²).
4. In cases of heavy fouling, divert the first 10-20% of cleaning solution to drain to prevent re-deposition of removed solids.
5. Rinse with RO permeate before returning system to service. When returning unit to service, divert product water to drain until any residual cleaning solution has been rinsed from system.

*Depending on the nature of the fouling, a soak period may be necessary for optimum results. Please contact PWT or your local distributor for custom cleaning procedure, or consult PWT's Technical Bulletin 503 for further cleaning recommendations.

ProDose XPRT™ – Scaling Prediction Software

ProDose XPRT™ uses the most accurate scaling prediction calculations available to accurately determine effective antiscalant dosage, and cleaning chemical usage. The user can enter multiple cases to study various operating conditions, directly enter concentrate analysis, and select the best PWT product and dosage for the application.

ProDose XPRT™ is available upon request only. Please contact your PWT representative for more information.

The screenshot displays the PWT ProDose software interface. At the top, there is a navigation bar with various settings: UNITS (US), TEMPERATURE (Fahrenheit), PERMEATE FLOW (81.00), RECOVERY (75.0%), ANTISCALANT (SpectraGuard Liquid), DOSAGE (2.95 PPM), SOURCE (Well Water), PROJECT NAME (Project 1), and CASE (1). Below this, the interface is divided into several sections:

- PROJECT INFORMATION:** Includes fields for CLIENT NAME (City of San Diego), PROJECT NAME (Project 1), LOCATION, PREPARED BY, DATE (5/11/2016), and WATER TYPE (Well Water).
- MEASUREMENTS:** Features preset units (CGS, Metric, U.S.), temperature (Deg F), flow rates (Gal/min), and mass units (lb). An "Enter" button is present.
- COMMENTS (OPTIONAL):** A large text area for user input.
- TOTAL CASES (1 AVAILABLE):** A table with columns for "Cases" and "Modified Date". The table shows one case with ID 1 and a modified date of 5/27/2016. Below the table is a field for "Selected Case Description".

The interface also includes a sidebar on the left with icons for PROJECT INFORMATION, WATER QUALITY, SYSTEM INFORMATION, CHEMICAL SELECTION, CALCULATIONS, and REPORT. At the bottom, there are navigation arrows and a small "4" in the corner.