



**Lewatit® S 8227** is a food grade, macroporous, weakly acidic cation exchange resin based on a crosslinked polyacrylate. It is bead-shaped and has a special bead size distribution for use in household filter systems and technical drinking water plants.

In its hydrogen form, **Lewatit**® **S 8227** is suitable for the decarbonisation and softening of drinking water, e.g. brewery water treatment, and the use in household filter systems.

When using **Lewatit® S 8227** to treat potable water and the aqueous solutions listed above, special care should be given to the initial cycles of the new resin. Please refer to the recommended start-up conditions available on request.

For a use in the treatment of potable water in France, a regeneration has to be done, according to the agreement, by only applying solutions of HCl or H2SO4, and for disinfection, only a solution of H2O2 may be used. Their concentrations have to comply with the present recommendations. These auxiliary products have to respect to purity criteria with respect to the below mentioned norms:

» HCI: NF EN 939

» H2SO4: NF EN 899

» H2O2: NF EN 902

The special properties of this product can only be fully utilized if the technology and process used correspond to the current state-of-the-art. Further advice in this matter can be obtained from Lanxess, Business Unit Liquid Purification Technologies.

This document contains important information and must be read in its entirety.







## Common Description

Delivery form	H <sup>+</sup>
Functional group	Carboxylic acid
Matrix	Crosslinked polyacrylate
Structure	Macroporous
Appearance	white, opak

## **Specified Data**

Uniformity coefficient		max.	1.8
Range of size for >=90 vol% of all beads		mm	0.4-1.6
Effective size	d10	mm	0.46-0.56
Total capacity (delivery form)		min. eq/L	4.3

This document contains important information and must be read in its entirety.







## Typical Physical and Chemical Properties

Bulk density for shipment	(+/- 5%)	g/L	770
Density		approx. g/mL	1.2
Water retention (delivery form)		approx. weight %	47-53
Volume change (H <sup>+</sup> - Na <sup>+</sup> )		max. approx. %	70
Stability pH range			0-14
Stability temperature range		°C	1-70
Storage temperature range		°C	-20-+40

## Operation

Operating temperature		max. °C	70
Operating pH range	during exhaustion		5-14
Bed depth for single column		min. mm	800
Back wash bed expansion per m/h (20°C)		%	5
Specific pressure loss kPa*h/m² (15°C)		kPa*h/m² (15°C)	1.8
Max. pressure loss during operation		kPa	250
Freeboard	during backwash	min. vol. %	60-80

### Regeneration

HCI regeneration	concentration	approx. wt. %	3-6
HCI regeneration	quantity co-current	min. g/L resin	120
HCI regeneration	quantity counter-current	min. g/L resin	70
H <sub>2</sub> SO <sub>4</sub> regeneration	concentration	approx. wt. %	0.5 - 0.8
H <sub>2</sub> SO <sub>4</sub> regeneration	quantity co-current	min. g/L resin	150
H <sub>2</sub> SO <sub>4</sub> regeneration	quantity counter-current	min. g/L resin	90
Regeneration contact		min. minutes	20
time			
Slow rinse at		min. BV	2
regeneration flow rate			
Fast rinse at service flow		min. BV	2
rate			

This document contains important information and must be read in its entirety.





### Additional Information & Regulations

### Safety precautions

Strong oxidants, e.g. nitric acid, can cause violent reactions if they come into contact with ion exchange resins.

### **Toxicity**

The safety data sheet must be observed. It contains additional data on product description, transport, storage, handling, safety and ecology.

### Disposal

In the European Community Ion exchange resins have to be disposed, according to the European waste nomenclature which can be accessed on the internet-site of the European Union.

### Storage conditions

It is recommended to store ion exchange resins at temperatures above the freezing point of water under roof in dry conditions without exposure to direct sunlight. If resin should become frozen, it should not be mechanically handled and left to thaw out gradually at ambient temperature. It must be completely thawed before handling or use. No attempt should be made to accelerate the thawing process.

#### Storage time

The recommended storage time for this product is explained in the technical document "Technical guidelines on the storage of Lewatit® ion exchange resins" available for download on our website. Please use the following link for more information: https://lanxess.com/en/products-and-brands/brands/lewatit/literature

### **Packaging**

The experience has shown that the packaging stability for reliable resin containment is limited to 24 months under the storage conditions described above. It is therefore recommended to use the product within this time frame; otherwise the packaging condition should be checked regularly.



**Head Office:** 54/18 Bui Quang La, An Hoi Tay Ward, HCMC, Vietnam

Branch Office: 77 Dong Hung Thuan 10B, Dong Hung Thuan Ward, HCMC, Vietnam

**Phone:** (028) 6258 5368 - (028) 6291 9568 **Email:** info@atswatertechnology.com

Website: www.atswatertechnology.com

This information and our technical advice – whether verbal, in writing or by way of trials – are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to check its validity and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility. Our products are sold in accordance with the current version of our General Conditions of Sale and Delivery.

**LANXESS Deutschland GmbH** 

Liquid Purification Technologies Kennedyplatz 1 50569 Koeln Germany

+49-221-8885-0 lewatit@lanxess.com

www.lanxess.com www.lpt.lanxess.com

This document contains important information and must be read in its entirety.

