

OptiClean™ G is a high pH (alkaline) powdered cleaner formulated to remove silt, colloids, organics, particulate, biological, and other acid insoluble foulants. Combining specially chosen chelants, surfactants, solubilizing and dispersing agents, OptiClean™ G provides excellent broad spectrum foulant removal. Ideal for periodic maintenance cleans, well water, and other light loading applications.

### Features / Benefits

- Readily dissolvable powdered cleaner provides efficient shipping and handling
- Buffered pH to maintain optimum cleaning performance throughout cleaning cycle
- Best results when used in a program that includes either OptiClean™ A or Lavasol™ 1

### Uses

- For use on reverse osmosis (RO), nanofiltration (NF), ultrafiltration (UF) and micro-filtration (MF) membranes
- Formulated to dissolve organic foulants from the membrane surface
- To aid in the removal of particulate, colloidal, microbiological and other acid insoluble foulants from the membrane surface

### Specifications

Appearance	White powder
pH (1% solution)	9.80 - 11.0

### Packaging

Pail: 25 lbs

Pail: 45 lbs

Pail: 55 lbs

Pail: 10 kg

Pail: 25 kg

Bulk Bag: 1000 kg

*For special packaging options, please contact PWT or your local distributor.*

**OptiClean™ G**  
POWDER MEMBRANE CLEANER

# OptiClean™ G

POWDER MEMBRANE CLEANER

## General Mixing & Application Instructions for OptiClean™ G

1. Inspect all cleaning system components to include CIP tank, hoses, and cartridge filters. Flush or replace if necessary. Fill cleaning tank with RO permeate or DI water. Turn on agitator or tank recirculation pump.
2. Slowly add OptiClean™ to cleaning tank (1 pound [0.45 kg] of OptiClean™ for every 12 gal [45 L] of water) and mix thoroughly. The solution pH should match product specification. If necessary, adjust pH with a membrane-approved chemical such as caustic, citric, sulfuric, or hydrochloric acid. The solution should be heated up to 45°C to improve cleaning efficacy.
3. Circulate solution in the same direction as the feed flow. Typical circulation times are 30-90 minutes.\* PWT recommends cleaning each stage of the system separately. Maximum flow rate per pressure vessel is 40 gpm (152 Lpm) for 8-inch elements and 10 gpm (38 Lpm) for 4-inch elements. Maximum pressure for cleaning is 60 psig (4.2 kg/cm<sup>2</sup>).
4. In cases of heavy fouling, divert the first 10-20% of cleaning solution to drain to prevent re-deposition of removed solids.
5. Rinse with RO permeate before returning system to service. When returning unit to service, divert product water to drain until any residual cleaning solution has been rinsed from system.

\*Depending on the nature of the fouling, a soak period may be necessary for optimum results. Please contact PWT or your local distributor for custom cleaning procedure, or consult PWT's Technical Bulletin 503 for further cleaning recommendations.

## ProDose XPRT™ – Scaling Prediction Software

ProDose XPRT™ uses the most accurate scaling prediction calculations available to accurately determine effective antiscalant dosage, and cleaning chemical usage. The user can enter multiple cases to study various operating conditions, directly enter concentrate analysis, and select the best PWT product and dosage for the application.

ProDose XPRT™ is available upon request only. Please contact your PWT representative for more information.

The screenshot displays the PWT ProDose software interface. At the top, there is a navigation bar with various settings: UNITS (US), TEMPERATURE (Fahrenheit), PERMEATE FLOW (81.00), RECOVERY (75.0%), ANTISCALANT (SpectraGuard Liquid), DOSAGE (2.95 PPM), SOURCE (Well Water), PROJECT NAME (Project 1), and CASE (1). Below this, a sidebar on the left contains icons for PROJECT INFORMATION, WATER QUALITY, SYSTEM INFORMATION, CHEMICAL SELECTION, CALCULATIONS, and REPORT. The main content area is divided into several sections: OVERVIEW (with fields for CLIENT NAME, PROJECT NAME, LOCATION, PREPARED BY, DATE, and WATER TYPE), MEASUREMENTS (with preset units, temperature, flow rates, and mass units), COMMENTS (OPTIONAL), and TOTAL CASES (1 AVAILABLE). A table shows one case with a modified date of 5/27/2016. The interface is clean and professional, with a dark grey header and light grey content areas.



**Headquarter:** 54/18 Bui Quang La, An Hoi Tay Ward, HCMC, Vietnam  
**Branch:** 77 Dong Hung Thuan 10B, Dong Hung Thuan Ward, HCMC, Vietnam  
**Phone:** (028) 6258 5368 – (028) 6291 9568  
**Email:** info@atswatertechnology.com  
**Website:** www.atswatertechnology.com